

Front Brake Deflector Install Subaru BRZ / Toyota GR86



Included Parts:

- Left Brake Deflector
- Right Brake Deflector
- 2x Bolts
- 2x Nuts
- 4x Washers

Install Procedure:

1. Securely jack up the vehicle.
2. Remove front wheel.
3. Loosen and remove two front brake caliper bolts.
4. Remove front brake caliper.
5. Secure front brake caliper to prevent caliper from hanging from the brake hose.
6. Remove front brake rotor.
7. Remove 3 front brake dust shield screws.



8. Remove brake dust shield.

9. Cut brake duct shield as shown in the photo below. Alternatively, you can completely remove the duct shield. Removing the shield entirely can cause premature failure of ball joint and tie rod dust boots.



10. Reinstall dust shield.
11. Position deflector as shown in the photos. Using the supplied hardware, install the brake deflector through the large hole in the front lower control arm. The order from top to bottom is: Bolt => Washer => Deflector => Lower Control Arm => Washer => Nut



12. Reinstall rotor, caliper and wheel.
13. Repeat for the opposite side.