

**GoPro Mount Install**  
**Toyota GR86 and Subaru BRZ 2022+**



---

**Included Parts:**

1. GoPro Mount

**Install Procedure:**

1. Remove the driver side headrest.
2. Slide the GoPro mount onto the headrest posts with the longer side towards the center of the car and the mount facing up.
3. Reinstall headrest onto the seat adjust to desired height
4. Tighten down the two bolts to clamp the GoPro mount onto the headrest
5. Install GoPro