

Element Extinguisher Mount Install Honda S2000



Included Parts:

1. Element Bracket
2. Element Fire Extinguisher (optional)

Install Procedure:

1. Remove the front outboard drive seat mount bolt.
2. Slide bracket under the seat mount and align the holes. Reinstall the mount bolt. Ensure the bracket is parallel with the side sills and torque to 16ft/lbs (22Nm).



3. Clip Element extinguisher into mount.

