

Intake Snorkel Subaru BRZ / Toyota GR86 2022+



Included Parts:

Intake Snorkel

Install Procedure:

1. Remove the front bumper
2. Remove the stock snorkel by unbolting the two bolts holding it to the cross bar
3. Remove the metal bushing from one of the rubber isolators on the stock snorkel
4. Remove the rubber isolator from the stock snorkel
5. Install the rubber isolator from the stock snorkel onto the Ansix Auto snorkel
6. Install the metal bushing into the rubber isolator
7. Put the Ansix Auto snorkel into place by sliding it into the stock airbox
8. Fasten the snorkel to the cross bar using one of the bolts removed in step 2
9. Reinstall bumper